



PART NUMBER

PFF85-440

DESCRIPTION

Engine Mount Insert

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Insert

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the engine mount from the vehicle.
2. Clean any dirt or flashing from the original mount.
3. Insert the Powerflex PFF85-440 Polyurethane Insert into the voids of the mount, shown in figure 1, ensuring that the tabs are fully inserted, as shown in figure 2
4. Refit and tension all hardware to manufacturers recommended torque settings.



Figure 1



Figure 2